

Specification Sheet Part No. 7300-7305

Strippable Booth Coating



Available in 1 and 5 Gallon Containers

INFORMATION / DIRECTIONS

Detro strippable booth coating is a elasticized latex paint designed for use on walls and ceilings in automotive and industrial paint booths. Its non-glare finish helps reduce shadows for truer color rendition. After 3 or 4 months simply strip old finish away and apply a fresh coat, your paint Booth looks like new (see removal).

- COVERAGE:**
- A. Approximately one hundred square feet per gallon. (@ 8mils)
 - B. Two mils per coat (using airless sprayer).
(MUST HAVE MINIMUM DRY FILM COATING OF 4 MILS(6-8 MILS RECOMMENDED)
- APPLICATION:**
- A. Ideal application procedure is an airless sprayer.
 - B. Product can be rolled or brushed.
 - C. Can be sprayed with conventional spray equipment with large fluid nozzle (THIS IS THE LEAST SATISFACTORY METHOD).
 - D. **DO NOT USE IN HEATED SPRAY BOOTHS EXCEEDING 150 DEGREES.**
 - E. First application: Minimum 2 or 3 coats
 - F. Re-coating: 1 or more coats (old finish must be stable to re-coat).
 - G. **Substrate must be a clean, dry, smooth, non-porous surface.**
- REDUCTION:**
- A. Reduction is not recommended, but if absolutely necessary, **NEVER** exceed 5 (five) percent (½ pint).
- REMOVAL:**
- A. When used in an unheated booth, check for ease of removal in four months.
 - B. When used in a heated booth, check for ease of removal in two months.
 - C. If finish is still stable, 7300 may be recoated rather than stripping.
 - D. Thin coats (under 8 mils) will be difficult to strip.
 - E. Strips best after 5 or 6 coats
- CLEANUP:**
- A. Strippable booth coating is a latex product, clean up tools and equipment with soap and water.
- DISPOSAL**
- A. Follow all local, state and federal regulations for latex paints

KEEP FROM FREEZING!!!!

Detro Manufacturing, Inc

1721 SE Grace Ave. • Battle Ground, WA. 98604

PH: (360) 687-9960 • FAX: (360) 687-7284 • ORDER DESK: Toll Free (877) 883-2869